

1. Turn ON the machine
2. Choose the program
3. Check the belts
4. Replace the belt that you have to
 - 4.1 Shut down the machine
 - 4.2 Open door
 - 4.3 Shut down dust collector
 - 4.4 Unlock and change the belt
5. Start machine → green line
6. Measure board
7. Insert board into machine

ORBS: OPEN FRAMES CLOSE SMALL
DUST COLLECTOR PUMP

MAINTANANCE